

# TILL SEEDING - SUB-TILLER



## RAPE EQUIPMENT - SUB-TILLER

Mounting set for Multi-Seeder, incl. mounting on a new Sub-Tiller.

One special dosing roll for rape/fertilizer is included in the price.

One of the following seeding methods is to be chosen as well as one of the Multi-Seeder models.


When sowing with disc coulters, a parallelogram-suspended disc coulters with double disc is used. The disc has a diameter of Ø350 and a thickness of 3 mm, while the pressure roller has a diameter of Ø330 and is either 75 or 50 mm wide.



|   |   |   |
|---|---|---|
| Band seeding<br>before the packer<br>roller | Seeding with disc<br>coulters with 75 mm<br>wide depth/press<br>wheel. 1 row placed<br>in centre line of the<br>tine, after packer<br>roller. | Seeding with disc<br>coulters<br>(12 cm btw./coulters)<br>with 75 mm wide depth/<br>press wheel. Placed in 2<br>rows around centre line<br>of the tine, after packer<br>roller. |
|---|---|---|

| Work Width, m              | Type     | Description   | No. of Tines | Item Number | Item Number | Item Number |
|----------------------------|----------|---|--------------|-------------|-------------|-------------|
| <b>THREE-POINT MOUNTED</b> |          |   |              |             |             |             |
| 3.00                       | Rigid    | Multi-Seeder without Auto-Controller  | 5            | 64507-12    | 64508-12    | 64510-12    |
| 3.00                       | Rigid    | Multi-Seeder with Auto-Controller   | 1* 5         | 64507-13    | 64508-13    | 64510-13    |
| 3.50                       | Rigid    | Multi-Seeder without Auto-Controller  | 7            | 64507-14    | 64508-14    | 64510-14    |
| 3.50                       | Rigid    | Multi-Seeder with Auto-Controller   | 1* 7         | 64507-15    | 64508-15    | 64510-15    |
| 4.00                       | Rigid    | Multi-Seeder without Auto-Controller  | 7            | 64507-16    | 64508-16    | 64510-16    |
| 4.00                       | Rigid    | Multi-Seeder with Auto-Controller   | 1* 7         | 64507-17    | 64508-17    | 64510-17    |
| 4.00                       | Foldable | Multi-Seeder with Auto-Controller   | 1* 7         | 64507-19    | 64508-22    | 64510-19    |
| 5.00                       | Foldable | Multi-Seeder with Auto-Controller   | 1* 9         | 64507-21    | 64508-23    | 64510-21    |
| <b>TRAILED</b>             |          |   |              |             |             |             |
| 4.00                       | Foldable | Multi-Seeder with Auto-Controller   | 1* 7         | 64507-25    | 64508-27    | 64510-24    |
| 5.00                       | Foldable | Multi-Seeder with Auto-Controller   | 1* 9         | 64507-22    | 64508-24    | 64510-22    |
| 6.00                       | Foldable | Multi-Seeder with Auto-Controller   | 1* 11        | 64507-23    | 64508-25    | 64510-23    |
| 7.00                       | Foldable | Multi-Seeder with Auto-Controller   | 1* 13        | 64507-24    | 64508-26    | -           |
| 3.00 - 4.00                | Rigid    | Platform w/steps. Recommended 2, when mounting fertilizer tank. (Price per unit)                                    | -            | 64509-50    | 64509-50    | 64509-50    |
| 4.00 - 7.00                | Foldable | Platform with steps   | -            | 63099-50    | 63099-50    | 63099-50    |
|                            |          | 50 mm narrow depth-press wheel, suitable for clay soil and sticky soil types (not suitable for lighter soil types). | 2*           | 0516898     | 0516898     | 0516898     |

<sup>1</sup>If multiple Multi-Seeders are mounted with Auto-Controller, up to 3 Multi-Seeders are operated from the same monitor in the cabin (not Front-Tank).  
<sup>2</sup>Same price but item number must be used.



## SLUG POISON EQUIPMENT - SUB-TILLER

Mounting set for Multi-Seeder, model TWIN or an extra Multi-Seeder, incl. mounting on a new Sub-Tiller.

One special dosing roll for slug poison is included in the price.

One of the following solutions is to be chosen as well as one of the Multi-Seeder models.



| PLACEMENT OF SLUG POISON IN BANDS AFTER THE ROLLER OR DEPTH WHEEL. |          |              |             |
|--|----------|--------------|-------------|
| Work Width, m  | Type     | No. of Tines | Item Number |
| <b>THREE-POINT MOUNTED</b>   |          |              |             |
| 3.00   | Rigid    | 5            | 64509-62    |
| 3.50   | Rigid    | 7            | 64509-66    |
| 4.00   | Rigid    | 7            | 64509-70    |
| 4.00   | Foldable | 7            | 64509-74    |
| 5.00   | Foldable | 9            | 64509-78    |
| <b>TRAILED</b>   |          |              |             |
| 4.00   | Foldable | 7            | 64509-75    |
| 5.00   | Foldable | 9            | 64509-79    |
| 6.00   | Foldable | 11           | 64509-80    |
| 7.00   | Foldable | 13           | 64509-81    |

<sup>1</sup>If multiple Multi-Seeders are mounted with Auto-Controller, up to 3 Multi-Seeders are operated from the same monitor in the cabin (not Front-Tank).

## FERTILIZER EQUIPMENT - SUB-TILLER

Mounting set for Multi-Seeder and Front-Tank, incl. mounting on a new Sub-Tiller.

Please choose one of the following solutions alongside a Multi-Seeder model or Front-Tank.



Multi-Seeder



Front-Tank

| FERTILIZER EQUIPMENT PLACES THE FERTILIZER JUST AFTER THE TINE FOR MIXING IN 2-10 CM |          |   |                |             |
|--|----------|---|----------------|-------------|
| Work Width, m  | Type     | Description                                       | No. of Tines   | Item Number |
| <b>THREE-POINT MOUNTED</b>   |          |   |                |             |
| 3.00   | Rigid    | HE-VA Front-Tank                                  | 5              | 64506-05    |
| 3.00   | Rigid    | Multi-Seeder without Auto-Controller              | <sup>2</sup>   | 64506-12    |
| 3.00   | Rigid    | Multi-Seeder with Auto-Controller                 | <sup>1/2</sup> | 64506-13    |
| 3.50   | Rigid    | HE-VA Front-Tank                                  | 7              | 64506-06    |
| 3.50   | Rigid    | Multi-Seeder without Auto-Controller              | <sup>2</sup>   | 64506-14    |
| 3.50   | Rigid    | Multi-Seeder with Auto-Controller                 | <sup>1/2</sup> | 64506-15    |
| 4.00   | Rigid    | HE-VA Front-Tank                                  | 7              | 64506-07    |
| 4.00   | Rigid    | Multi-Seeder with Auto-Controller                 | <sup>1/2</sup> | 64506-17    |
| 4.00   | Foldable | HE-VA Front-Tank                                  | 7              | 64506-08    |
| 5.00   | Foldable | HE-VA Front-Tank                                  | 9              | 64506-09    |
| <b>TRAILED</b>   |          |   |                |             |
| 4.00   | Foldable | HE-VA Front-Tank                                  | 7              | 64506-19    |
| 4.00   | Foldable | HE-VA Front-Tank mounted on Sub-Tiller            | 7              | 64506-39    |
| 4.00   | Foldable | HE-VA Front-Tank mounted on Sub-Tiller with discs | 7              | 64506-40    |
| 5.00   | Foldable | HE-VA Front-Tank                                  | 9              | 64506-10    |
| 5.00   | Foldable | HE-VA Front-Tank mounted on Sub-Tiller            | 9              | 64506-30    |
| 5.00   | Foldable | HE-VA Front-Tank mounted on Sub-Tiller with discs | 9              | 64506-41    |
| 6.00   | Foldable | HE-VA Front-Tank                                  | 11             | 64506-11    |
| 6.00   | Foldable | HE-VA Front-Tank mounted on Sub-Tiller            | 11             | 64506-33    |
| 6.00   | Foldable | HE-VA Front-Tank mounted on Sub-Tiller with discs | 11             | 64506-42    |
| 7.00   | Foldable | HE-VA Front-Tank                                  | 13             | 64506-18    |
| 7.00   | Foldable | HE-VA Front-Tank mounted on Sub-Tiller            | 13             | 64506-36    |
| 7.00   | Foldable | HE-VA Front-Tank mounted on Sub-Tiller with discs | 13             | 64506-43    |

<sup>1</sup>If multiple Multi-Seeders are mounted with Auto-Controller, up to 3 Multi-Seeders are operated from the same monitor in the cabin (not Front-Tank).

<sup>2</sup>The hydraulic fan is equipped with air distributor with 2 or 3 outlets and will also supply the Multi-Seeders with air.