TILL SEEDING - SUB-TILLER





RAPE EQUIPMENT - SUB-TILLER

Mounting set for Multi-Seeder, incl. mounting on a new Sub-Tiller.

One special dosing roll for rape/fertilizer is included in the price.

One of the following seeding methods is to be chosen as well as one of the Multi-Seeder models.

When sowing with disc coulters, a parallelogram-suspended disc coulter with double disc is used. The disc has a diameter of Ø350 and a thickness of 3 mm, while the pressure roller has a diameter of Ø330 and is either 75 or 50 mm wide.







Work Width, m	Type	Description		No. of Tines	Band seeding before the packer roller Item Number	Seeding with disc coulters with 75 mm wide depth/press wheel. 1 row placed in centre line of the tine, after packer roller. Item Number	Seeding with disc coulters (12 cm btw./coulters) with 75 mm wide depth/ press wheel. Placed in 2 rows around centre line of the tine, after packer roller. Item Number
THREE-POINT MOUNTED							
3.00	Rigid	Multi-Seeder without Auto-Controller		5	64507-12	64508-12	64510-12
3.00	Rigid	Multi-Seeder with Auto-Controller	1*	5	64507-13	64508-13	64510-13
3.50	Rigid	Multi-Seeder without Auto-Controller		7	64507-14	64508-14	64510-14
3.50	Rigid	Multi-Seeder with Auto-Controller	1*	7	64507-15	64508-15	64510-15
4.00	Rigid	Multi-Seeder without Auto-Controller		7	64507-16	64508-16	64510-16
4.00	Rigid	Multi-Seeder with Auto-Controller	1*	7	64507-17	64508-17	64510-17
4.00	Foldable	Multi-Seeder with Auto-Controller	1*	7	64507-19	64508-22	64510-19
5.00	Foldable	Multi-Seeder with Auto-Controller	1*	9	64507-21	64508-23	64510-21
TRAILED							
4.00	Foldable	Multi-Seeder with Auto-Controller	1*	7	64507-25	64508-27	64510-24
5.00	Foldable	Multi-Seeder with Auto-Controller	1*	9	64507-22	64508-24	64510-22
6.00	Foldable	Multi-Seeder with Auto-Controller	1*	11	64507-23	64508-25	64510-23
7.00	Foldable	Multi-Seeder with Auto-Controller	1*	13	64507-24	64508-26	-
3.00 - 4.00	Rigid	Platform w/steps. Recommended 2, when mounting fertilizer tank. (Price per unit)		-	64509-50	64509-50	64509-50
4.00 - 7.00	Foldable	Platform with steps		-	63099-50	63099-50	63099-50
50 mm narrow depth-press wheel, suitable for clay soil and sticky soil types (not suitable for lighter soil types).			2*	-	0516898	0516898	0516898

*1*If multiple Multi-Seeders are mounted with Auto-Controller, up to 3 Multi-Seeders are operated from the same monitor in the cabin (not Front-Tank).*
*2*Same price but item number must be used.*





SLUG POISON EQUIPMENT - SUB-TILLER

Mounting set for Multi-Seeder, model TWIN or an extra Multi-Seeder, incl. mounting on a new Sub-Tiller.
One special dosing roll for slug poison is included in the price.
One of the following solutions is to be chosen as well as one of the Multi-Seeder models.







PLACEMENT OF SLUG POISON IN BANDS AFTER THE ROLLER OR DEPTH WHEEL.			
Work Width, m	Type	No. of Tines	Item Number
THREE-POINT MOUNTED			
3.00	Rigid	5	64509-62
3.50	Rigid	7	64509-66
4.00	Rigid	7	64509-70
4.00	Foldable	7	64509-74
5.00	Foldable	9	64509-78
TRAILED			
4.00	Foldable	7	64509-75
5.00	Foldable	9	64509-79
6.00	Foldable	11	64509-80
7.00	Foldable	13	64509-81

[1] If multiple Multi-Seeders are mounted with Auto-Controller, up to 3 Multi-Seeders are operated from the same monitor in the cabin (not Front-Tank).*

FERTILIZER EQUIPMENT - SUB-TILLER

Mounting set for Multi-Seeder and Front-Tank, incl. mounting on a new Sub-Tiller.

Please choose one of the following solutions alongside a Multi-Seeder model or Front-Tank.





Multi-Seeder



Front-Tank

FERTILIZER EQUIPMENT PLACES THE FERTILIZER JUST AFTER THE TINE FOR MIXING IN 2-10 CM					
Work Width, m	Type	Description		No. of Tines	Item Number
THREE-POINT MOUNTED					
3.00	Rigid	HE-VA Front-Tank		5	64506-05
3.00	Rigid	Multi-Seeder without Auto-Controller	2*	5	64506-12
3.00	Rigid	Multi-Seeder with Auto-Controller	1*/2*	5	64506-13
3.50	Rigid	HE-VA Front-Tank		7	64506-06
3.50	Rigid	Multi-Seeder without Auto-Controller	2*	7	64506-14
3.50	Rigid	Multi-Seeder with Auto-Controller	1*/2*	7	64506-15
4.00	Rigid	HE-VA Front-Tank		7	64506-07
4.00	Rigid	Multi-Seeder with Auto-Controller	1*/2*	7	64506-17
4.00	Foldable	HE-VA Front-Tank		7	64506-08
5.00	Foldable	HE-VA Front-Tank		9	64506-09
TRAILED					
4.00	Foldable	HE-VA Front-Tank		7	64506-19
4.00	Foldable	HE-VA Front-Tank mounted on Sub-Tiller		7	64506-39
4.00	Foldable	HE-VA Front-Tank mounted on Sub-Tiller with discs		7	64506-40
5.00	Foldable	HE-VA Front-Tank		9	64506-10
5.00	Foldable	HE-VA Front-Tank mounted on Sub-Tiller		9	64506-30
5.00	Foldable	HE-VA Front-Tank mounted on Sub-Tiller with discs		9	64506-41
6.00	Foldable	HE-VA Front-Tank		11	64506-11
6.00	Foldable	HE-VA Front-Tank mounted on Sub-Tiller		11	64506-33
6.00	Foldable	HE-VA Front-Tank mounted on Sub-Tiller with discs		11	64506-42
7.00	Foldable	HE-VA Front-Tank		13	64506-18
7.00	Foldable	HE-VA Front-Tank mounted on Sub-Tiller		13	64506-36
7.00	Foldable	HE-VA Front-Tank mounted on Sub-Tiller with discs		13	64506-43

[1] If multiple Multi-Seeders are mounted with Auto-Controller, up to 3 Multi-Seeders are operated from the same monitor in the cabin (not Front-Tank).*
[2*] The hydraulic fan is equipped with air distributor with 2 or 3 outlets and will also supply the Multi-Seeders with air.