

TILL SEEDING - STEALTH



RAPE EQUIPMENT - STEALTH

Mounting set for Multi-Seeder, incl. mounting on a new Stealth.

One special dosing roll for rape/fertilizer is included in the price.


One of the following seeding methods is to be chosen as well as one of the Multi-Seeder models.



Band seeding before the packer roller



Seeding with disc coulters with 75 mm wide depth/press wheel. 1 row placed in centre line of the tine, after packer roller.



Wide sowing before packer roller

Work Width, m	Type	Description	No. of Tines	Item Number	Item Number	Item Number
THREE-POINT MOUNTED						
3.00	Rigid	Multi-Seeder without Auto-Controller	6	64485-01	64485-31	64485-61
3.00	Rigid	Multi-Seeder with Auto-Controller	^{1*} 6	64485-02	64485-32	64485-62
3.50	Rigid	Multi-Seeder without Auto-Controller	7	64485-05	64485-35	64485-65
3.50	Rigid	Multi-Seeder with Auto-Controller	^{1*} 7	64485-06	64485-36	64485-66
4.00	Rigid	Multi-Seeder without Auto-Controller	8	64485-09	64485-39	64485-69
4.00	Rigid	Multi-Seeder with Auto-Controller	^{1*} 8	64485-10	64485-40	64485-70
4.00	Foldable	Multi-Seeder with Auto-Controller	^{1*} 8	64485-13	64485-43	64485-73
5.00	Foldable	Multi-Seeder with Auto-Controller	^{1*} 10	64485-17	64485-47	64485-77
6.00	Foldable	Multi-Seeder with Auto-Controller	^{1*} 12	64485-21	64485-51	64485-81
TRAILED						
4.00	Foldable	Multi-Seeder with Auto-Controller	^{1*/3*} 8	64485-15	64485-45	64485-75
5.00	Foldable	Multi-Seeder with Auto-Controller	^{1*/3*} 10	64485-19	64485-49	64485-79
6.00	Foldable	Multi-Seeder with Auto-Controller	^{1*/3*} 12	64485-23	64485-53	64485-83
-	Rigid	Platform w/steps. Recommended 2, when mounting fertilizer tank. (Price per unit)	-	64485-95	64485-95	64485-95
-	Foldable	Platform with steps	-	63099-50	63099-50	63099-50
50 mm narrow depth-press wheel, suitable for clay soil and sticky soil types (not suitable for lighter soil types).			^{2*} -	0516898	0516898	0516898

^{1*}If multiple Multi-Seeders are mounted with Auto-Controller, up to 3 Multi-Seeders are operated from the same monitor in the cabin (not Front-Tank).

^{2*}Same price but item number must be used.

^{3*}4.00-6.00 m trailed models: Disc coulters **cannot** be retrofitted on existing machines.



SLUG POISON EQUIPMENT - STEALTH

Mounting set for Multi-Seeder, model TWIN or an extra Multi-Seeder, incl. mounting on a new Stealth.

One special dosing roll for slug poison is included in the price.

One of the following solutions is to be chosen as well as one of the Multi-Seeder models.



PLACEMENT OF SLUG POISON IN BANDS AFTER THE ROLLER OR DEPTH WHEEL.				
Work Width, m	Type	Placement	No. of Tines	Item Number
THREE-POINT MOUNTED				
3.00	Rigid	Band after roller	6	64486-01
3.50	Rigid	Band after roller	7	64486-05
4.00	Rigid	Band after roller	8	64486-09
4.00	Foldable	Band after roller	8	64486-13
5.00	Foldable	Band after roller	10	64486-17
6.00	Foldable	Band after roller	12	64486-21
3.00	Rigid	Band after depth wheel	6	64486-02
3.50	Rigid	Band after depth wheel	7	64486-06
4.00	Rigid	Band after depth wheel	8	64486-10
4.00	Foldable	Band after depth wheel	8	64486-14
5.00	Foldable	Band after depth wheel	10	64486-18
6.00	Foldable	Band after depth wheel	12	64486-22
TRAILED				
4.00	Foldable	Band after roller	8	64486-15
5.00	Foldable	Band after roller	10	64486-19
6.00	Foldable	Band after roller	12	64486-23
4.00	Foldable	Band after depth wheel	8	64486-16
5.00	Foldable	Band after depth wheel	10	64486-20
6.00	Foldable	Band after depth wheel	12	64486-24

If multiple Multi-Seeders are mounted with Auto-Controller, up to 3 Multi-Seeders are operated from the same monitor in the cabin (not Front-Tank).

FERTILIZER EQUIPMENT - STEALTH

Mounting set for Multi-Seeder and Front-Tank, incl. mounting on a new Stealth.

Please choose one of the following solutions alongside a Multi-Seeder model or Front-Tank.



Multi-Seeder



Front-Tank

FERTILIZER EQUIPMENT PLACES THE FERTILIZER JUST AFTER THE TINE FOR MIXING IN 2-10 CM				
Work Width, m	Type	Description	No. of Tines	Item Number
THREE-POINT MOUNTED				
3.00	Rigid	Front-Tank	6	64486-40
3.00	Rigid	Multi-Seeder without Auto-Controller	^{2*} 6	64486-60
3.00	Rigid	Multi-Seeder with Auto-Controller	^{1*/2*} 6	64486-70
3.50	Rigid	Front-Tank	7	64486-41
3.50	Rigid	Multi-Seeder without Auto-Controller	^{2*} 7	64486-61
3.50	Rigid	Multi-Seeder with Auto-Controller	^{1*/2*} 7	64486-71
4.00	Rigid	Front-Tank	8	64486-42
4.00	Rigid	Multi-Seeder with Auto-Controller	^{1*/2*} 8	64486-72
4.00	Foldable	Front-Tank	8	64486-43
5.00	Foldable	Front-Tank	10	64486-45
6.00	Foldable	Front-Tank	12	64486-47
TRAILED				
4.00	Foldable	Front-Tank	8	64486-44
5.00	Foldable	Front-Tank	10	64486-46
6.00	Foldable	Front-Tank	12	64486-48

^{1*}If multiple Multi-Seeders are mounted with Auto-Controller, up to 3 Multi-Seeders are operated from the same monitor in the cabin (not Front-Tank).

^{2*}The hydraulic fan is equipped with air distributor with 2 or 3 outlets and will also supply the Multi-Seeders with air.